

QUICK
START
GUIDE

ACCTIM
RADIO CONTROLLED

Thank you for purchasing your Acctim radio controlled watch. Please read this guide carefully and store it in a safe place for future reference.

Your watch is guaranteed for 12 months*. **Register your watch at acctimwatches.com to extend your guarantee to 24 months for free.**

INITIAL SETUP

Ensure all hands are at 12:00. Remove the plastic spacer and gently press the crown in. Hold the correct button to sync your watch. After setup, your watch will automatically re-synchronize every night, at 2:00am.

SYNCING YOUR WATCH




1. Make sure all three hands are at the 12:00 position before syncing. If necessary, pull out the crown with the seconds hand at 12:00 and adjust.

2. With all three hands set to 12:00, gently push the crown in and press and hold the appropriate button:

Press button B for UK (MSF) signal
Press button C for EU (DCF) signal

The seconds hand will revolve once.

3. Your watch will take 3 to 10 minutes to synchronize. Pressing the appropriate button again will halt synchronization. For best results, lie your watch on its side or face up whilst it is syncing.



For more detailed instructions and to register your guarantee, please visit www.acctimwatches.com




For our full range of Acctim radio controlled clocks and technologies, please visit www.acctim.com

CHECKING FOR SYNC SIGNAL

Press button A to check for sync signal. If the seconds hand points to 12:00 your watch is receiving a signal. If the second hand points to 6:00, it is not.

ADJUSTING THE TIME

Your watch automatically adjusts itself for daylight savings. You do not need to adjust your watch manually. Pulling out and pushing back the crown will disable the radio controlled functionality. See “Travelling” for further details.



TRAVELLING

If you're travelling to a location which cannot receive a radio control signal, simply pull out the crown, adjust the hands to local time and gently press the crown back in. The radio controlled functionality of the watch will be disabled. To enable radio controlled functionality, just follow the setting procedure again.

BATTERY

Your Acctim watch uses one (1) CR1616 battery. To replace, please take your watch to a jeweller or professional watch repair shop. After replacing the battery your watch will require re-syncing.

TROUBLESHOOTING

My watch isn't receiving a signal.

TVs, mobile phones, computers and other electrical appliances may cause undesirable signal interference. Your watch may find a stronger signal close to the window. Try positioning the watch on a windowsill, away from appliances when syncing.

There is no radio control signal in my area.

Pull out the crown, adjust the hands to local time and gently push the crown back in. The RC function will be automatically disabled and your watch will operate as a standard quartz watch. To restart the RC function, see “Syncing Your Watch”.

My seconds hand seems off.

Sometimes hard knocks or vibrations can cause the hands to move irregularly, although the internal movement is keeping accurate time. If when pressing button A the seconds hand does not point at 12:00 or 6:00, follow the below steps:

- Press button B or C and the second hand will attempt to turn to 12:00.
- You now have 20 seconds to adjust the seconds hand. Press button A to forward the second hand by one second. Press A as many times as necessary to adjust back to 12:00. Your watch will now attempt to sync.

DISPOSAL

Do not dispose of this product with household waste. For the proper treatment, recovery and recycling please take this product to the appropriate collection point. If you are unsure of where this is contact your local authority.

Improper disposal may be harmful to the environment.



acctimwatches.com
service@acctim.com

GUARANTEE

*Guaranteed for 12 months from the date of purchase against any faults arising from defective materials or manufacture. Your guarantee does not cover replacement batteries, straps or bracelets (unless due to fault); damage to lens or water penetration. Damage caused through careless handling, misuse or in transit is expressly excluded. Should this watch fail within 12 months please return it in the first instance to your retailer.

If you have any problems or do not understand any part of these instructions please contact:

Customer Help Line: 01908 449208
Mon – Fri 9am-4.30pm